



TASKI[®] Swingo[®] 150 E

Preparation



Remove tank from machine by pulling the lever. Remove dosing cup by turning it to the left.



Fill solution tank with fresh water up to indicated mark. Label with mark is on solution tank side.



Dose cleaning product into dosing cup and pour into solution thank. Make sure dosing cup is exactly turned



Remount tank in machine until it locks into place and press the hook to lock tank.

Operation



Plug cable and press main switch to turn machine on. Switch will light up.





Hold machine firmly by the handle. Bring it to working position by pressing red food pedal.



Adjust brush pressure by turning knob slowly anticlockwise until red light turns off. Red light indicates that motor is overloaded.



Press first suction switch (no lamp) and afterwards water pump switch (lamp lights up).



If red light goes on and off immediately while working, adjustment is correct. Cleaning can start following direction of arrows (picture).







by pulling the hook. Unlock



Empty both tanks. Rinse and







completely dry!



Hook filter housing in tank paying attention that front tooth is correctly inserted.



Remove brush housing cover by unsliding two side latches. Rotate yellow clips until they unhook to release squeegees.



Put machine on left side to remove squeegees. Wash squeegees under running room temperature water.



Check squeegee condition before installing. Replace squeegees and note front & rear writing on squeegee top.













Press rotation lock, turn brush holder anticlockwise and pull roller to clean.

reinstall brush roller. Refit brush holder and turn it clockwise until Rotate yellow clip. Remove Check suction conveyor that it is



Store machine with open tank

ATTENTION: Do not use the machine before you have read and understood the operating instructions!



www.diversey.com

©2018 Diversey, Inc. All Rights Reserved. 67493 MASTER 03/18