

**1 Preparation**

Unplug cable of battery charger, then plug red battery cut-off plug into the machine

Mount squeegee.

Mount brush unit.

Fill solution tank with clean water and dose the cleaning solution.

Or use Diversey Care cleaning solution dosing system.

**6**

Release parking position

**7 Operation**

To turn on the machine press the start button for 3 seconds.

Start solution supply.

Adjust solution flow.

Start vacuum motor.

**11**

Adjust height of the handle.

Use orange fixation for floated cleaning.

Start brush rotation by pressing the levers and clean the floor.

Front squeegee for removing the water when going backwards. Use the lever right-hand!

**Maintenance**

Remove water sieves and rinse with water.

**16**

Drain, rinse and clean the recovery tank.

Remove and clean floater unit.

Empty fresh water tank and clean solution filter.

Bring machine into parking position.

Remove and clean squeegee.

**21**

Remove and clean brush unit.

Remove and clean brush unit.

Wipe machine with moist cloth.

Store machine with open lid for ventilation and in parking position.

Unplug the red battery cut-off plug, then plug in the cable of the battery charger.

