







Unplug cable of battery charger, wind up and place on machine (holder).



Fill solution tank with clean water.



Dose cleaning product into dosing aid, pour it into the solution thank. Then rinse the dosing aid and close the solution tank with it.



Mount squeegee with 'click' mechanism and attach the suction hoses on both sides.



Position tool(s) precisely under the lifted brush unit.

Operation



Turn the machine on with the key switch.



Lower the brush unit. The brushes should then couple to the unit automatically. If not repeat from pt. 5 on.



Start vacuum motor, start & adjust solution flow.



Clean the floor. When re-filling the tank and after use always switch off the machine with the key switch.



Drain recovery tank and rins with fresh water, then drain



Remove the floating unit (filter and floater) with a rotation of the yellow filter in anticlockwise direction and clean under a running water tap.



Clean solution filter



Remove tools with foot pedal (while brush unit is in upper position).



Clean tools and allow to air dry



Remove and clean squeegee.



Wipe machine with moist clot



Plug in cable of battery charger



Flip dosing aid.



Store machine with partially open lid (lid rests on dosing aid) for ventilation.



Store the squeegee on the hoo on the side of machine.